

IMPORTANT INFORMATION FOR PLAYING 14" DISCS

It may prove difficult to properly play 14" discs on some of our CVS-14 turntables because of a minor clearance problem at the arm rest. What happens is that the user will not be able to place the arm on the extreme outer edge of the record.

Fortunately, this is easily cured. The only tool required is a pair of cutting "dykes" as illustrated at the right, or a pair of large toe nail clippers.



What has to be done is to carefully line up the cutting edges of the tool with the protrusion which interferes with setting the arm at the edge of the record. You must cut just after the "U" shape of the arm lift. See the illustration at the left.

When you are done the result should look something like the illustration at the bottom.

